





USER MANUAL

CPU WATER COOLING
GLACIER240


1 INTEL
AMD




2 INTEL
AMD



3 INTEL
AMD




4 AMD




AMD Socket
FM2+/FM2/FM1/AM3+/AM3/AM2

5 AMD




AMD Socket
FM2+/FM2/FM1/AM3+/AM3/AM2

6 AMD



AMD Socket
FM2+/FM2/FM1/AM3+/AM3/AM2

7 AMD



AMD Socket
FM2+/FM2/FM1/AM3+/AM3/AM2

8 AMD

